

Firmware crisis recovery

Date of Create: 2022/10/27

ELITEGROUP COMPUTER SYSTEMS CO., LTD.

 ELITEGROUP	Instruction
精英電腦 股份有限公司	Firmware crisis recovery
Pages: 2 of 2	

➤ **Crisis recovery:**

1. Prepare an USB key. (Format to FAT or FAT32 type first.)
2. Unzip the BIOS file. Change name [SP41MDXXX.bin](#) to [SP41MD.bin](#) Copy [SP41MD.bin](#) to root directory of the USB key.
3. Insert the USB key to the USB port.
4. Turn off the system. Skip this step if the system is already power off.
5. Plug-in an adapter and hold the <Fn> and <R> both.
6. Power-on the system by power button.
7. The system will enter crisis mode and recovery BIOS automatically.